

**E-314**

# 深型チタンシェラカップ 蓋付き

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、シェラカップです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

**セット内容 (各部の名称)**


本体



蓋



取扱説明書 (本書)

**スペック**

- 材質:チタニウム
- 本体サイズ:φ109×77mm(取手除く、蓋付き)
- 重量:75g
- 容量:360ml

**安全上の注意事項** ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

**⚠ 注意 ケガや本体破損、物品破損として拡大被害の原因となる行為を示します。**

- 加熱中は本体、取手及び蓋が非常に高温になりますのでやけどにご注意ください。加熱後はしばらく本体、中身を冷ましてから取り扱ってください。
- 加熱する際は、バーナーを水平で安定した場所に設置し、必ずゴトクに本製品が乗って安定していることを確認してからご使用ください。
- 加熱する際はバーナーの炎が底面より大きくならないように火力を調整してください。
- 製品の変形・変色の原因となりますので空焚き及び、空焚きに近い調理等はしないでください。
- 初めてご使用する際及び使用後は柔らかいスポンジに中性洗剤に付け、丁寧に洗浄してください。また、洗浄に硬い素材のたわしなどを使用するとキズの原因になります。
- 洗った後は乾いた布等でよく拭き取り、乾燥させてください。
- 満水まで熱いものを入れないでください。蓋を持ち上げる時などにやけどするおそれがあります。
- 本体の変色または傷が付くおそれがありますので、食器用洗浄機、食器用乾燥機の使用は控えてください。
- 本製品を電子レンジ・オーブンで使用しないでください。火災・爆発のおそれがあります。
- 食品を長時間カップに入れておくとお色が変わることがあります。
- 蓋は燃焼器などで直接加熱しないでください。変形、破損するおそれがあります。
- 蓋は蓋や小皿以外の用途で使用しないでください。

**品質保証について**

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。

- |                          |                               |                         |
|--------------------------|-------------------------------|-------------------------|
| 1. 素材の経年劣化による損害など商品の寿命   | 5. その他製造上の欠陥以外による製品の故障        | 9. 摩擦によるパーツの変化及びそれによる故障 |
| 2. 改造および粗雑な取扱いによる故障      | 6. ゴミやさびによる故障                 | 10. 他社製品との組み合わせによる故障    |
| 3. 取扱説明書で禁止されている取扱いによる故障 | 7. 分解したことによる不具合の発生または破損       |                         |
| 4. 不測の事故による商品の故障         | 8. 落下やその他の衝撃による部品の変形や破損による不具合 |                         |

**修理について**

- 本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。
- 修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。
- 修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。
- 修理品の運賃並びに修理費については以下のように規定させていただきます。
  1. 保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。
  2. 保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。

E-314

# Deep Backpacker's Cup with Lid

Thank you for purchasing a Snow Peak product. This product is a lightweight cup with a lid. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

**Contents (Name of the Parts)**



body



Lid



Instruction Manual  
(This Manual)

**Specifications**

- Materials : Titanium
- Size:  $\phi 109 \times 77 \text{mm}$  (Excluding handle, with lid) / dia. 109×77mm
- Weight : 75g / 2.6oz
- Capacity: 360ml / 12.2fl oz

**Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.**

**⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.**

- Please be careful not to burn yourself while heating this product, as the body, handle, and lid will become extremely hot. After heating, please allow some time for the main body and contents to cool down before handling.
- When heating, please ensure that the burner is placed horizontally in a stable location and that the product is securely positioned on the grid before use.
- When heating, please adjust the heat to ensure that the flame of the burner does not exceed the bottom surface.
- Do not heat the cup when empty or near empty, as it may cause deformation or discoloration.
- Before using this product for the first time, please wash it with the soft side of the sponge with a neutral detergent. Do not use a scrub brush or abrasive surface of a sponge. These items may cause scratches.
- After washing, wipe off thoroughly with a dry cloth and dry.
- Please do not pour hot liquids up to the brim. Overfilling increases the risk of burning when lifting the lid.
- Do not use a dishwasher or dish dryer as it may cause discoloration or scratches on the main body.
- Do not use this product in a microwave oven or oven. There is a risk of fire or explosion.
- Please do not leave food in the cup for more a long time. Prolonged food storage may cause discoloration.
- Do not directly heat the lid with a burner or similar device. Heating the lid on its own may cause deformation or damage.
- Do not use the lid for any purpose other than covering the cup or as a small dish.

**Warranty**

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following:

- |  |   |
|--|---|
| <ol style="list-style-type: none"> <li>1. Material deterioration caused by age</li> <li>2. Damage caused by modifications or rough handling</li> <li>3. Damage caused by inappropriate use not mentioned in the instruction manual</li> <li>4. Damage caused by unexpected accidents</li> <li>5. Any damage other than defects in the manufacturing process</li> </ol> | <ol style="list-style-type: none"> <li>6. Damage caused by dust or rust</li> <li>7. Damage and defects caused by dismantling the product</li> <li>8. Damage and defects caused by dropping, jolting or other shocks</li> <li>9. Deterioration or failure of parts due to friction</li> <li>10. Damage caused by the use of the product in combination with another manufacturer's products</li> </ol> |
|--|---|

**Repair**

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service.
- When you request repairs, please make sure that the product is dry and clean.
- Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred.
- Transportation and repair costs are determined as follows.
  1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak.
  2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.