

CARSON®

NeckLight™

With Ultrabright COB LEDs

Congratulations on selecting your new Carson NeckLight™! In order to achieve optimum performance, please follow instructions for proper use and care.




NL-20

PRODUCT SPECIFICATION


Brightness Setting:	High / Low	Dimensions:	7.5" x 1.9" x 11.7"
Illumination:	COB LEDs	Batteries:	3 AAA (not included)
Weight:	0.331 lbs		

INSTALLING BATTERIES

1. Remove battery door.




2. Insert 3 AAA batteries in the correct polarity, then reattach battery door.



WARNING: Use only alkaline batteries. Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Insert in direction indicated. Rechargeable batteries not recommended.

USING NECKLIGHT

1. Place NeckLight around neck and adjust to desired position.
2. Each arm is equipped with its own light. For brightness levels, press once for low and twice for high.



Note: Flexible NeckLight has many uses. Perfect as a reading light, craft light, work light, indoor/outdoor activity light and so much more. Simply wrap around an object and focus light where needed.

CARE

Clean using microfiber lens cloth. Do not use any abrasives, chemical cleaners, or solvents.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

For warranty information, visit www.carson.com/warranty

www.carson.com

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000