

IBEX PRO CRAMPON

User Guide

Climbing Crampons for Arc, Surge, AfterBurner, Magneto, Burton Hitchhiker, & Nitro Vertical Bindings
Heel Locker and Riser Kit compatible

SIZING	BOARD WAIST	NESTED CRAMPON INSIDE WIDTH
NARROW	25cm or less	12.8cm
REGULAR	25-26cm (most boards)	13.8cm
WIDE	26cm or more	14.8cm



IBEX PRO CRAMPON USER GUIDE




1
Slide the crampton from right to left into the crampton mounting claws on the Touring Bracket. Slide crampton **ALL** the way to the left until it hits the stop position.



2
Rotate the crampton down until it lays flat on the board half.

NOTE: Failure to fully engage crampton before use can damage product. With practice crampons can be inserted while strapped in. Kneeling helps. Practice on the flats!



3
As the slope steepens, use the climbing wires as normal – they will push the crampton teeth fully into the snow for consistent traction. When you stride forward, pressure will be released, allowing the crampton to glide freely over the snow.

Now, slide them in and enjoy 4-wheel drive for your splitboard!