

MR. CHOMPS CRAMPON

User Guide

Pin Mount Bindings
Blaze & Burner

SIZING	BOARD WAIST	CRAMPON INSIDE WIDTH
REGULAR	less than 26cm	13.8cm
WIDE	26cm or more	14.8cm

 sparkrandd.com



MR. CHOMPS CRAMPON USER GUIDE



1 Check that your board is set up correctly with LT brackets and either single or preferably dual height wires.



2 Pivot the binding forward and hook the crampon underneath the touring pin.



3 Rotate the crampon down until it lays flat on the board half.

4 As the skin track steepens, flip up either your short or long climbing wire:



Short Wire

To use the short wire, just flip it up and go.



Long Wire

To use the long wire, also flip up the wire on the crampon. This will allow the crampon to float over the snow as you stride forward and dig in when you weight your heels.